



## FITTING TOOL



### Measuring Your Hand for a Proper Fit

Measure the circumference of your hand just above your thumb. Reference the chart below for the correct glove size.

### Low Voltage Insulating Rubber Gloves

Hand Circumference	Glove Size
6 1/2" - 7 1/2"	8
7 1/2" - 8 1/2"	9
8 1/2" - 9 1/2"	10
9 1/2" - 11"	11
Over 11"	12

Comasec Safety, Inc. • PO Box 1219 • 8 Niblick Road • Enfield, CT 06083-1219  
(800)333-1219 • Fax (860)741-0881 • info@comasecsafety.com

#### NOTE:

When fitting high voltage gloves (class 1 and above), it may be necessary to move up one size since these gloves will not stretch as easily as the low voltage gloves (class 00 and 0).